



ILLUSTRATED PARTS LIST FOR



SINGER Machine

107G235

THE SINGER COMPANY




107 G 235 - 10 (0671)

| | |
|------------|----------------------------|
| 160-850 | ARM COVER (TOP) SCREW (2) |
| 160-850 | FACE PLATE SCREW |
| 1186-850 | ARM COVER (TOP) SCREW (2) |
| 1186-850 | FACE PLATE SCREW |
| 1654-850 | THREAD RETAINER NUT |
| 51220-853 | THREAD GUIDE (UPPER) SCREW |
| 200582-850 | THREAD GUIDE (LOWER) SCREW |

| | |
|--------|------------------------------|
| 202412 | THREAD GUIDE (ON TOP OF ARM) |
| 210593 | THREAD GUIDE (LOWER) |
| 502667 | THREAD RETAINER |
| 508153 | ARM COVER (TOP) |
| 508154 | FACE PLATE |
| 508166 | THREAD GUIDE (UPPER) |

PART NO. DESCRIPTION


PART NO. DESCRIPTION



107 G 235 - 20 (0671)

| | |
|------------|---|
| 238-650 | BED SLIDE SPRING SCREW (2) |
| 141566-633 | MACHINE PULLEY POSITION SCREW |
| 141567-633 | MACHINE PULLEY SET SCREW |
| 200577-633 | BED PLATE SCREW (2) |
| 200577-633 | BED PLATE (BACK) SCREW (2) |
| 210505 | BED PLATE (BACK) |
| 210616 | BED SLIDE (FRONT) CPL. NOS. 508506 AND TWO EACH 238 |
| 224485 | THROAT PLATE |


| | |
|------------|--|
| 272142 | ARM SHAFT BALL (BACK) |
| 500196-850 | MACHINE GROUNDING WIRE SCREW |
| 500350-850 | TAKE-UP LEVER GUARD SCREW (2) |
| 508150 | MACHINE PULLEY CPL. NOS. 141566, 141567 AND 272142 |
| 508167 | ARM SHAFT BUSHING (FRONT) OIL PACKING PLUG |
| 508168 | NEEDLE BAR FRAME CAP |
| 508216 | TAKE-UP LEVER GUARD |
| 508506 | BED SLIDE SPRING |
| 512008 | MACHINE GROUNDING WIRE LOCK WASHER |
| 603291 | MACHINE GROUNDING WIRE SYMBOL |



107 G 235 - 40 (0671)

| | |
|------------|--|
| 1901-16-1 | NEEDLE |
| 200070-650 | NEEDLE BAR FRAME PITMAN ECCENTRIC STUD SET SCREW |
| 200125-633 | NEEDLE SET SCREW |
| 200172-650 | THREAD GUIDE SCREW |
| 200175-650 | NEEDLE THREAD GUIDE SCREW |
| 200334-633 | NEEDLE BAR FRAME HINGE |
| 210534-633 | GUIDE STUD SET SCREW |
| 210542 | NEEDLE BAR FRAME CPL. NOS. 210546 AND 224317 |
| 210546 | NEEDLE BAR FRAME WITH 200070 |

| | |
|--------|--|
| 210542 | NEEDLE BAR FRAME GUIDE STUD |
| 210557 | NEEDLE BAR FRAME PITMAN ECCENTRIC STUD |
| 224317 | NEEDLE BAR CPL. NOS. 200125, 200175 AND 249270 |
| 224387 | THREAD GUIDE |
| 249270 | NEEDLE BAR THREAD GUIDE |
| 396536 | NEEDLE BAR FRAME CPL. NOS. 200172, 210542 AND 224387 |
| 508163 | NEEDLE BAR FRAME HINGE STUD |



107 G 235 - 50 (0671)


| | |
|------------|---|
| 200074-850 | PRESSER FOOT SCREW |
| 200086-833 | PRESSER BAR POSITION GUIDE LEVER PINCH SCREW |
| 200132-850 | TAKE-UP LEVER OILING FELT SCREW |
| 200260-850 | PRESSER BAR LIFTING RELEASING LEVER BRACKET |
| | GUIDE SCREW |
| 200352-833 | PRESSER BAR POSITION GUIDE SET SCREW |
| 200352-833 | PRESSER BAR BUSHING SET SCREW |
| 200475-850 | PRESSER BAR BUSHING (UPPER) THUMB SET SCREW |
| 200653-850 | PRESSER BAR LIFTER HINGE SCREW |
| 201497-850 | PRESSER BAR THUMB SCREW (PRESSURE REGULATING) |
| 202401 | TAKE-UP LEVER OILING FELT |
| 202338 | PRESSER BAR CPL. NOS. 200074 AND 244033 |
| 202337 | PRESSER BAR POSITION GUIDE |
| 202338 | PRESSER BAR POSITION GUIDE LEVER WITH 200086 |
| 206608 | PRESSER BAR LIFTING RELEASING LEVER BRACKET |
| | SPRING |

| | |
|--------|---|
| 207072 | PRESSER BAR BUSHING |
| 210758 | PRESSER BAR SPRING (LIGHT) |
| 224478 | PRESSER BAR BUSHING (UPPER) |
| 224479 | PRESSER FOOT |
| 236106 | PRESSER BAR SPRING STOP ROD |
| 244033 | PRESSER BAR (HOLLOW) |
| 244084 | PRESSER BAR BUSHING (UPPER) THUMB SET SCREW |
| | PACKING (FELT) |
| 508157 | PRESSER BAR LIFTING RELEASING LEVER BRACKET |
| 508215 | PRESSER BAR LIFTER |
| 508219 | PRESSER BAR WASHER |

PART NO. DESCRIPTION

PART NO. DESCRIPTION


THREAD TENSION, TENSION RELEASING DEVICE



107 G 235 - 60 (0671)



| | |
|------------|--|
| 50305-850 | THREAD STUD SET SCREW |
| 140321-850 | THREAD CONTROLLER SPRING REGULATOR SET SCREW |
| 200287-833 | THREAD RETAINER STUD SET SCREW |
| 200382-850 | THREAD GUIDE SCREW |
| 202410 | THREAD CONTROLLER SPRING |
| 210956 | THREAD RETAINER BRACKET WITH 200397 |
| 210957 | THREAD RETAINER STUD |
| 210958 | THREAD RETAINER STUD COLLAR |
| 210992 | THREAD RETAINER SPRING |
| 210993 | THREAD RETAINER SLEEVE |
| 223438 | TENSION SPRING |
| 244048 | TENSION DISC (BACK) |
| 244049 | TENSION DISC (FRONT) |
| 263547 | TENSION RELEASE WASHER |

| | |
|------------|---|
| 263548 | TENSION RELEASING PIN |
| 263550 | TENSION STUD WASHER |
| 263552 | THREAD CONTROLLER SPRING REGULATOR WITH 50305 |
| 350613-806 | TENSION STUD WITH 263550 |
| 500795 | TENSION THUMB NUT |
| 508179 | TENSION CPL. NOS. 202410, 223438, 244048, 244049, 263547, 263548, 263552, 350613, 500795 AND 508180 |
| 508180 | TENSION SPRING WASHER |
| 508182 | TENSION RELEASE PLUNGER |
| 508196 | THREAD RETAINER BRACKET CPL. NOS. 210957, 210958, 210992, 210993 AND 210956 |



| | |
|------------|---|
| 200054-850 | NEEDLE BAR FRAME PITMAN PINCH SCREW |
| 200236-850 | NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET HINGE AND STOP SCREW 1 |
| 200378-850 | NEEDLE VIBRATING GEAR SHAFT COLLAR SET SCREW (2) |
| 200380-853 | NEEDLE VIBRATING GEAR SET SCREW 2 |
| 200382-850 | NEEDLE VIBRATING REGULATING SCREW CHECK SCREW |
| 200390-850 | NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET FLANGE SCREW 1/2 |
| 200409-850 | NEEDLE VIBRATING REGULATING SCREW |
| 200677-851 | NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET PLUNGER SPRING STOP SCREW |
| 201526-850 | NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET HINGE AND STOP SCREW NUT 1/2 |
| 202277 | NEEDLE BAR FRAME PITMAN OIL PACKING (WICK) |
| 202300 | NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET |
| 202301 | NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET PLUNGER |


203172 NEEDLE VIBRATING GEAR FRICTION WASHER
210550 NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET
CPL. NOS. 202300, 210552 AND TWO EACH 200256
AND 201525
210552 NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET
FLANGE WITH TWO 200383
210556 NEEDLE BAR FRAME PITMAN CPL. NOS. 200054 AND
202277
210559 NEEDLE VIBRATING GEAR SHAFT COLLAR WITH TWO
200378
210699 NEEDLE VIBRATING GEAR (SPIRAL) WITH TWO 200382
508164 NEEDLE VIBRATING GEAR SHAFT
508211 NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET
PLUNGER SPRING



107 G 235 - 80 (0671)


| | |
|------------|--|
| 200566-850 | NEEDLE VIBRATING GEAR SHAFT FLANGE SCREW (3) |
| 500345-850 | NEEDLE VIBRATING GEAR SHAFT FLANGE COVER SCREW (3) |
| 508170 | NEEDLE VIBRATING GEAR SHAFT FLANGE |
| 508171 | NEEDLE VIBRATING REGULATION ADJUSTING UNIT CPL. |
| | NOVS. 508172 TO 508174 |

| | |
|--------|--|
| 508172 | NEEDLE VIBRATING GEAR SHAFT FLANGE COVER |
| 508173 | BIGHT AMPLITUDE ADJUSTING KNOB |
| 508174 | BIGHT AMPLITUDE ADJUSTING KNOB RETAINER |



- 200054-850 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE LEVER
PINCH SCREW
200054-850 PULLER FEED ROLL (UPPER) BAR BRACKET SUPPORT PINCH
SCREW
200256-850 PULLER FEED ROLL (UPPER) BAR BRACKET SCREW
200347-033 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE SET SCREW
200352-033 PULLER FEED ROLL (UPPER) BAR BRACKET SET SCREW
200374-033 PULLER FEED ROLL (UPPER) BRACKET SET SCREW
200378-850 PULLER FEED ROLL (UPPER) HINGE STUD SET SCREW
200379-850 PULLER FEED ROLL (UPPER) BRACKET POSITION SCREW
200550-850 PULLER FEED ROLL (UPPER) BAR LIFTER HINGE SCREW
200955-850 PULLER FEED ROLL (UPPER) BAR LIFTING BRACKET SET SCREW
201458-850 PULLER FEED ROLL (UPPER) BAR THUMB SCREW
224403 PULLER FEED ROLL (UPPER) RUBBER FACED
224404 PULLER FEED ROLL (UPPER) BAR LIFTING BRACKET
WITH 200950
236112 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE
236113 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE LEVER
WITH 200054

- 237015 PULLER FEED ROLL (UPPER) BAR LIFTER STOP PIN
237021 PULLER FEED ROLL (UPPER) BAR
237023 PULLER FEED ROLL (UPPER) BAR BRACKET SUPPORT
WITH 200054
237026 PULLER FEED ROLL (UPPER) BAR SPRING
237027 PULLER FEED ROLL (UPPER) BAR SPRING WASHER
237028 PULLER FEED ROLL (UPPER) BRACKET CPL. NOS. 200374,
200378 AND 200396
237029 PULLER FEED ROLL (UPPER) HINGE STUD
237037 PULLER FEED ROLL (UPPER) BAR LIFTER
508217 PULLER FEED ROLL (UPPER) BAR BRACKET CPL. 200550,
201458, 224404, 236112, 237021, 237026, 237027, 237028,
237037 AND 508218
508218 PULLER FEED ROLL (UPPER) BAR BRACKET CPL. NOS. 200347,
200352 AND 237015




107 G 235 - 100 (0671)

200106-850 FEED DOG SCREW (2)
 200383-850 FEED DRIVING ROCK SHAFT STOP COLLAR SET SCREW (4)
 201522-850 FEED BAR HINGE SCREW (DRIVING)
 202623-850 FEED HINGE SCREW (DRIVING) NUT
 200641-850 FEED DRIVING ROCK SHAFT

202625 FEED DRIVING ROCK SHAFT STOP COLLAR (2) WITH
 FOUR 200383
 210512 FEED BAR
 210513 FEED BAR CPL. NOS. 200641, 201522, 202623 AND 210512
 210516 FEED DOG

PART NO. DESCRIPTION


PART NO. DESCRIPTION



107 G 235 - 110 (0671)

| | |
|------------|---|
| 1518-B50 | PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW NUT |
| 1620-B50 | PULLER FEED CLUTCH DRIVING CONNECTION HINGE SCREW NUT |
| 200035-B50 | PULLER FEED CLUTCH DRIVING CRANK PINCH SCREW |
| 200039-B50 | PULLER FEED ROLL LOWER SHAFT BRACKET SCREW (4) |
| 200337-B50 | PULLER FEED CLUTCH CAP RETAINING SCREW STUD SCREW |
| 200374-B50 | PULLER FEED ROLL LOWER SET SCREW |
| 200396-B50 | PULLER FEED ROLL LOWER SHAFT COLLAR SET SCREW (2) |
| 201201-B50 | PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW |
| 201301-B50 | PULLER FEED CLUTCH CAP RETAINING SCREW STUD SCREW NUT |


| | |
|------------|--|
| 205797 | PULLER FEED ROLL LOWER SHAFT COLLAR WITH 200386 |
| 224480 | PULLER FEED CLUTCH DRIVING CONNECTION |
| 224478 | PULLER FEED ROLL LOWER SHAFT |
| 225585 | PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW WASHER |
| 237007 | PULLER FEED CLUTCH DRIVING CRANK WITH 200035 |
| 237077 | PULLER FEED ROLL LOWER RUBBER FACED CPL NOS. 200374 AND 200396 |
| 237019 | PULLER FEED ROLL LOWER SHAFT BRACKET 2 |
| 500378-B50 | PULLER FEED CLUTCH DRIVING CONNECTION HINGE SCREW |



107 G 235 - 120 (0671)

| | |
|-------------|---|
| 1036-B30 | PULLER FEED CLUTCH DRIVE CONNECTION SET SCREW |
| 50375-B56 | PULLER FEED CLUTCH SLEEVE SET SCREW 12 |
| 66-152 | PULLER FEED CLUTCH PULLER PLUNGER 6 |
| 131-17 | PULLER FEED CLUTCH PULLER 6 |
| 121-725 | PULLER FEED CLUTCH WASHER |
| 206-126-B33 | PULLER FEED CLUTCH CAP SCREW 13 |
| 206-270-B50 | PULLER FEED COVER PLATE SCREW 12 |
| 201-437-B50 | PULLER FEED CLUTCH CAP RETAINING SCREW STUD |
| 224-482 | PULLER FEED CLUTCH BRAKE |
| 224-429 | PULLER FEED CLUTCH BRAKE CPL NOS 224-488 AND 2635-4 |
| 224-699 | PULLER FEED CLUTCH CAP |
| 224-491 | PULLER FEED CLUTCH DRIVE |


224492 PULLER FEED CLUTCH (DRIVE) CPL NOS 224491 AND 263574
224494 PULLER FEED CLUTCH PULLER SPRING 6
224495 PULLER FEED CLUTCH SLEEVE WITH TWO SCOTS
224496 PULLER FEED CLUTCH CPL NOS 131725, 120457, 224489,
224490, 224492, 224495, 268442 WITH THREE SCOTTS AND
SIX EACH 68152, 131717 AND 224494
237016 PULLER FEED COVER PLATE
263574 PULLER FEED CLUTCH PULLER WEAR PLATE 6
268442 PULLER FEED CLUTCH DRIVE CONNECTION CPL NOS
1036 AND 350636
350636-B33 PULLER FEED CLUTCH (DRIVE) CONNECTION FINISH SCREW



107 G 235 - 130 (0671)

| | |
|------------|---|
| 200038-850 | FEED DRIVING CONNECTION CRANK PINCH SCREW |
| 200054-850 | FEED LIFTING CONNECTION CRANK PINCH SCREW |
| 200344-850 | FEED DRIVING CONNECTION PINCH SCREW |
| 200382-850 | FEED LIFTING CONNECTION PINCH SCREW |
| 200378-850 | FEED LIFTING CONNECTION CRANK SET SCREW |
| 200367-830 | FEED LIFTING CONNECTION ECCENTRIC SET SCREW |
| 200360-830 | NEEDLE VIBRATING FINION SET SCREW 2 |
| 200437-850 | FEED LIFTING CONNECTION ECCENTRIC POSITION SCREW |
| 200345-850 | FEED DRIVING CONNECTION HINGE SCREW |
| 200545-850 | FEED LIFTING CONNECTION HINGE SCREW |
| 201518-850 | FEED DRIVING CONNECTION HINGE SCREW NUT |
| 201518-850 | FEED LIFTING CONNECTION HINGE SCREW NUT |
| 201297 | FEED DRIVING CONNECTION CPL. NOS. 200054 AND 203101 |
| 201306 | FEED LIFTING CONNECTION CPL. NOS. 200054 AND 203101 |


| | |
|--------|---|
| 202624 | FEED DRIVING CONNECTION CRANK WITH 200038 |
| 203101 | FEED LIFTING CONNECTION OIL PACKING WICK |
| 203101 | FEED DRIVING CONNECTION OIL PACKING WICK |
| 210569 | FEED LIFTING CONNECTION CRANK CPL. NOS. 200050, 200378 AND 210545 |
| 210645 | FEED LIFTING CONNECTION CRANK |
| 210700 | NEEDLE VIBRATING FINION SPIRAL WITH TWO 200382 |
| 266053 | FEED LIFTING CONNECTION ECCENTRIC CPL. NOS. 200382 AND 200437 |
| 396530 | FEED LIFTING CONNECTION CPL. NOS. 200545, 201518, 210589 AND 210569 |
| 396533 | FEED DRIVING CONNECTION CPL. NOS. 200545, 201518, 210589 AND 202624 |



107 G 235 - 140 (0671)

| | |
|------------|--|
| 200327-833 | ARM SHAFT CONNECTION BELT PULLEY SET SCREW |
| 200383-850 | FEED DRIVING ECCENTRIC REGULATING SCREW CHECK SCREW |
| 200429-850 | FEED DRIVING ECCENTRIC REGULATING SCREW |
| 200602-850 | ARM SHAFT CONNECTION BELT PULLEY POSITIONING SCREW |
| 200607-850 | FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING STOP SCREW |
| 201014-850 | FEED DRIVING ECCENTRIC REGULATING BRACKET STOP AND HINGE SCREW (2) |
| 201525-850 | FEED DRIVING ECCENTRIC REGULATING BRACKET STOP SCREW AND HINGE SCREW (2) |
| 202253 | ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2) |



| | |
|--------|---|
| 202300 | FEED DRIVING ECCENTRIC REGULATING BRACKET |
| 202301 | FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER |
| 202635 | ARM SHAFT CONNECTION BELT PULLEY CPL. NOS. 200327, 200602 AND TWO 202253 |
| 203098 | FEED DRIVING ECCENTRIC REGULATING BRACKET CPL. NOS. 202300, 202635 AND TWO EACH 201014 AND 201525 |
| 224400 | ARM SHAFT CONNECTION BELT REINFORCED REG. FEED |
| 237523 | FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING |
| 508155 | FEED REGULATING SPINDLE INSERT |



107 G 235 - 160 (0671)

| | |
|------------|---|
| 200076-850 | BOBBIN CASE STOP SCREW |
| 210764-850 | HOOK WASHER NEEDLE GUARD SCREW |
| 210736-850 | BOBBIN CASE TENSION SPRING SCREW |
| 210536-850 | HOOK GIB SCREW (3) |
| 210541-850 | BOBBIN CASE LATCH STOP SCREW |
| 210735-850 | BOBBIN CASE TENSION SPRING REGULATING SCREW |
| 210531 | HOOK GIB |
| 210541 | HOOK WASHER NEEDLE GUARD |
| 210734 | BOBBIN CASE LATCH LEVER |
| 210735 | BOBBIN CASE LATCH PULCRUM PIN |
| 210736 | BOBBIN CASE LATCH SPRING |
| 210764 | BOBBIN CASE STOP |
| 210945 | BOBBIN CASE CAP |


| | |
|--------|---|
| 210913 | BOBBIN CASE LATCH |
| 210914 | BOBBIN CASE LATCH CPL. NOS. 210734, 210735 AND 210913 |
| 224432 | HOOK (SEWING) |
| 224433 | HOOK CPL. NOS. 210536, 210541, 224432 WITH THREE 200596 |
| 224440 | BOBBIN CASE CAP CPL. NOS. 200592, 201016 AND 508530 |
| 224441 | BOBBIN CASE CAP CPL. NOS. 200964, 210735, 210914 AND 224440 |
| 224442 | BOBBIN CASE CPL. NOS. 210846 AND 224441 |
| 224443 | HOOK AND BOBBIN CASE CPL. NOS. 224433 AND 224442 |
| 233028 | BOBBIN |
| 508530 | BOBBIN CASE TENSION SPRING |



107 G 235 - 170 '0671)

| | |
|------------|--|
| 200082-000 | FOOT LIFTER LEVER EXTENSION SCREW 1/2" |
| 200242-000 | FOOT LIFTER LIFTING LEVER HINGE SCREW |
| 200273-000 | FOOT LIFTER LIFTING LEVER SPRING SCREW |
| 224475 | FOOT LIFTER LIFTING LEVER |
| 224476 | FOOT LIFTER LIFTING LEVER EXTENSION |





| | |
|--------|----------------------------------|
| 224486 | FOOT LIFTER LIFTING LEVER ROD |
| 232131 | FOOT LIFTER LIFTING LEVER WASHER |
| 233390 | FOOT LIFTER LIFTING LEVER WASHER |
| 508195 | FOOT LIFTER LIFTING LEVER SPRING |







107 G 235 - 190 (0671)

001K05-000 ATTACHMENT SCREW
228391 D. 1/2" WITH FOUR 511599
511599-000 D. 1/4" WOOD SCREW (4)

512021 GROUNDING WIRE WASHER
603271 GROUNDING WIRE




107 G 235 - 200 (0671)



107 G 235 + 210 (0671)

120440 SCREW DRIVER (LONG)
225554 WRENCH (STEEL)


228476 SCREW DRIVER (ROBBIN CASE)
239352 WRENCH (HEXAGON)



107 G 235 - 220 (0671)

200530-650 FOOT LIFTER LIFTING LEVER ROD COUPLING
SCREW
203058 FOOT LIFTER LIFTING LEVER ROD COUPLING WITH
200530

228430 FOOT LIFTER LIFTING LEVER CHAIN
228440 FOOT LIFTER LIFTING LEVER CPL. NOS. 228430 AND
TWO 511591
511591-805 FOOT LIFTER LIFTING LEVER MOUNTING WOOD SCREW (2)



107 G 235 - 230 (0671)

| | |
|------------|--|
| 500416-850 | PULLEY SET SCREW |
| 500417-819 | STOP LATCH TRIP LEVER HINGE SCREW |
| 500418-819 | STOP LATCH SCREW |
| 500419-819 | BRACE CLAMP SCREW |
| 500420-819 | TENSION BRACKET SCREW |
| 500421-819 | TENSION STUD THUMB NUT |
| 500422-819 | UNIVERSAL BOBBIN WINDER FOR "V" BELT DRIVES CPL. |
| 503780 | NOS. 500417, 500418, 500419, 503903, 503904, 503906, 503907, 503908, 503909, 503910, 503911, 503912, 503913, 503914, 503915, 503916 AND 503922 |
| 503903 | BOBBIN WINDER AND TENSION BRACKET BASE |
| 503784 | FRAME WITH 503903 |
| 503905 | FRAME OIL CUP (PLASTIC) |
| 503906 | FRAME HINGE PIN |
| 503907 | FRAME SPRING FLUNGER |
| 503908 | FRAME SPRING |
| 503909 | SPINDLE |

| | |
|------------|---|
| 503910 | PULLEY WITH 500416 |
| 503911 | STOP LATCH THUMB LEVER |
| 503912 | STOP LATCH TRIP LEVER |
| 503913 | STOP LATCH THUMB LEVER HINGE JOINT STUD |
| 503914 | STOP LATCH |
| 503915 | BRACKET (RUBBER) |
| 503916 | BRACE CLAMP |
| 503917 | TENSION BRACKET WITH 503918 |
| 503918 | TENSION STUD |
| 503919 | TENSION DISC |
| 503920 | TENSION SPRING |
| 503921 | TENSION BRACKET SCREW WASHER |
| 503922 | TENSION BRACKET CPL. NOS. 500420, 500421, 503917, 503920, 503921 AND TWO 503919 |
| 511604-855 | BOBBIN WINDER MOUNTING WOOD SCREW (2) |